

## Advices for a successful installation

### Phase 1: Top

Mount the top with the edge greater than 75 cm from ground using the brackets (A) and (B) supplied.

### Phase 2: Column

Unscrew the roof of the column (C) and remove it with the wing mirror above the door (D). Support the column to the top and use the rear holes of the brackets (E) as a mask for trace the fixing holes in wall. Subsequently fixing the column remembering to extract the electrical cable designed to lamp from the back.

### Phase 3: Lamp

Connect your electric cable to the power supply (F). Support the power supply in the upper niche and pass the cable power for the lamp into the hole on the roof. After fixing before the upper wing mirror and then the roof, proceed to fix and connect the lamp.

### Phase 4: Hydraulics

Route the hoses water into the two holes on the top as per drawing and connect them to the appropriate attacks.

### Phase 5: Washbasin

Screw the washbasin on the top and proceed by connecting the drain, spacer and siphon.

### Phase 6: Lower carter

Attach the support chassis (H) line in column and with the edge greater than 65,5 cm from ground as per drawing. Finally, fix the case front of the carter (I).

Your composition is now complete.  
Thank you for choosing a Spoldi Idea Bagno's product.

